

SUPER MOD. IV. (FREQ. COUNTER KIT FITS P. MADISON BASE)

INSTRUCTIONS:

1. REMOVE COVERS ON RADIO
2. REMOVE FRONT COVER PLATE
(BE CAREFUL, THERE IS A SCREW LOCATED IN CENTER OF PLATE INSIDE.)
3. REMOVE CLOCK (TERMINATE WIRES)
4. OBTAIN $\frac{1}{8}$ " SMOKED PLEXI-GLASS PLATE
CUT $1\frac{13}{16}$ " WIDE BY $5\frac{3}{4}$ " LONG. CUT HOLES FOR FREQ COUNTER MODULE.
5. INSTALL COUNTER. HOOK UP 2000 μ F 25VOLT CAP AND INSTALL 15 OHM RESISTOR (1WATT) AS PER DRAWING
6. FREQ. COUNTER MODULE HAS A MEMORY SWITCH AND IS MADE BY TEKNIK MODEL FC-106.
7. CONTACT SECRET CB FOR MORE INFO IF NEEDED.





