

MIDLAND 77-849

Adjust L7, L11, and L12 for maximum power.
Adjust RV2 for 100% modulation.
RV4: RF panel adjustment.
Connect pins 9 and 10 of IC1 together for more frequencies.

MIDLAND 76-863

Adjust L7, L11, and L12 for maximum power.
Adjust RV2 for 100% modulation.
RV521: Antenna warning light adjustment.
Connect pin 9 of IC1 to pin 10 of IC1 for more frequencies.

MOTOROLA T4000A/05A/10A/20A

Cut VR305 and CR206 for 100% modulation.

MIDLAND 77-861

Adjust T5, L4, L5, and L13 for maximum power.
Adjust VR1 for lo power set.
Cut D2 for 100% modulation.
VR2: RF panel adjustment.
Connect pin 10 of IC101 to 4.70V source for more frequencies.

KRACO KCB 4088

Adjust VR104 for 100% modulation.

MEDALLION 63-240

Adjust VR2 for 100% modulation.
Tune L6, L4, L3, and L1 for maximum power.
Adjust VR1 for RF panel meter adjustment.
Connect pin 6 of PLL to 7.45V source and connect pin 7 of PLL to 7.45v source for more frequencies.

GENERAL ELECTRIC 3-5800A

Adjust VR5 for maximum modulation.