

SPECIFIC INSTALLATION INSTRUCTIONS (CONT)

FOR VSB-1

MIDLAND 79-893 -

- Compressor- Remove D601 and D602. Solder BLACK wire to C603 and WHITE wire to C605.
- Expander- Remove C92. Solder BLACK wire towards collector of TR17, and WHITE wire towards D29.

NO PREAMP

PEARCE-SIMPSON BENGAL SSB -

- Compressor- Remove C189. Insert BLACK wire in positive side of hole towards R160, and the WHITE wire towards the MIKE GAIN CONTROL.
- Expander- Remove C88. Insert BLACK wire to positive side and WHITE wire towards CB/PA switch.

NO PREAMP

PRESIDENT AR-14 -

- Compressor- Remove C47. Solder BLACK wire to the common of TR9 and the WHITE wire to R27. Remove TR8.
- Expander- Lift Brown wire at the volume control. Connect brown and BLACK wires together. Resolder WHITE wire to the volume control.

PREAMP RECOMMENDED

PRESIDENT AR-44 -

- Compressor- Remove C89, and insert the BLACK lead to the input and the WHITE lead to the output of the vacated cap. (towards R53).
- Expander- Remove C56, and solder the BLACK lead to the collector, and the WHITE lead towards R52. Remove TR14.

NO PREAMP