

# SPECIFIC INSTALLATION INSTRUCTIONS (CONT)

## FOR VSB-1

### STANDARD HORIZON 29A -

Compressor- Remove C305. Install the BLACK wire to the positive side of hole and the WHITE wire towards R251. Remove TR219.

Expander- Remove C242. Install the BLACK wire into the positive side of the hole and the WHITE wire towards R250.

NO PREAMP

### TEABERRY MIGHTY T-

Compressor- Remove C711 and insert compressor leads in place of the capacitor, with the BLACK lead as the input and the WHITE lead as the output.

Expander- Remove C503 and insert the expander leads in place of the capacitor, with the BLACK lead as the input and the WHITE lead as the output.

NO PREAMP

### TRAM D42-

Compressor- Remove C85. Solder the BLACK wire towards R89, and the WHITE wire towards R84. Clip CD11.

Expander- Remove C39. Install pre-amp. Solder the BLACK wire to the output of pre-amp and the WHITE wire towards the volume control.

PREAMP REQUIRED

### TRAM D201-

Compressor- Remove C615. Solder the BLACK wire towards plate of V600. Solder the WHITE wire towards R626. Clip D605.

Expander- Remove C432. Solder the BLACK wire towards C431 and the WHITE wire towards C619.

NO PREAMP

*USB-1  
will  
not  
work  
on  
TRAMS*