

SIMPLE CURE FOR RX-TX TRACKING PROBLEMS

INSTRUCTIONS:

Ground A or B side of Relay Contacts to reduce clarifier voltage on either REC. or XMIT.
Ground Point (A) if you wish to Lower Voltage on Transmit.
Ground Point (B) if you wish to Lower Voltage on Receive.

