

COBRA 146GTL Continued:

REMOVE Rubber Pad at point C for access.

* ADD 1,000ufd 16VDC Electrolytic Capacitor for stabilization of 8 V Source.

CLARIFIER:

1. Remove D30 and replace with our Super Diode (SCB Cat. #28).
 2. Make the cut at point labelled A in drawing. Run a wire from A to Cathode of D50.
 3. Install jumper B as shown in drawing.
 4. Solder in a 1,000 ufd/16VDC capacitor as shown in drawing (A to G).
 5. Clip or remove D32.
-

PM77 POWER MODULATOR KIT

Like to have a power mike but don't like the bulky, battery eating mikes currently available? Try our new PM77 Power Modulator Kit. It can be used with any type of microphone or even an electret to really give you signal PUNCH. It also works fantastic in conjunction with the VSB-1 compandor (Secret CB Kit #102) for unbeatable modulation. Order Secret CB Kit #143.

