

POINTER'S

BEFORE converting/modifying/tune-up, verify that unit does work flawlessly. This can save many headaches! REMEMBER...Just because its "right out of the box" doesn't mean it works. Check it out FIRST. Then proceed carefully.

I recommend doing the following:

1. Check out unit on RX, TX, AM, USB, LSB.
2. Check all functions, RF gain, Squelch, etc.
3. When you are satisfied everything is okay, turn off/unplug, and remove units covers.
4. Proceed with frequency conversion.
5. Adjust VCO, tune-up, check operation.
6. Proceed to Clarifier Mod.
7. Check operation.
8. Reassemble.
9. Retest and verify frequencies.
10. Make frequency chart, mark center on clarifier.
11. Install in customers car (if mobile), set SWR, make contact.
If base, connect to antenna, make contact.

"HELP LINE"

If anyone knows the where abouts of a supplier for SBE parts let us know here at "SECRET CB" so we can spread the word.