



**SCHEMATIC OF THE
Hallicrafters
LINEAR AMPLIFIER
MODEL HT-41**

NOTES:
ALL RESISTOR VALUES ARE IN OHMS (K=1000, MEG=1,000,000).
ALL CAPACITORS VALUES ARE IN μFD UNLESS MARKED OTHERWISE.

Lethally high voltages are present inside the amplifier unit.
Never remove either top or bottom cover when power line is connected.
DO NOT attempt to operate unit when covers are removed:

Safety Instructions
Use Caution when servicing.

Disclaimer:
Although the greatest care has been taken while compiling these documents,
we cannot guarantee that the information is 100% correct.
Copyright © 2004 B. Bolin