

List of components

C ₁	= 3,3 pF	50 V	N750
C ₂	= 47 μF	16 V	
C ₃	= 10 nF	50 V	
C ₄	= 27 pF	50 V	N750
C ₅	= 10 nF	50 V	
C ₆	= 10 nF	50 V	
C ₇	= 33 pF	50 V	N750
C ₈	= 10 nF	50 V	
R ₁	= 1,0 KΩ	¼W	
R ₂	= 22 KΩ	¼W	
R ₃	= 470 Ω	¼W	
R ₄	= 1,0 KΩ	¼W	
R ₅	= 18 Ω	½W	
R ₆	= 470 Ω	¼W	
R ₇	= 56 KΩ	¼W	
R ₈	= 22 KΩ	¼W	
R ₉	= 180 Ω	¼W	
R ₁₀	= Potenziometer	4,7 KΩ	
R ₁₁	= 4,7 KΩ	¼W	
D ₁ = D ₂ = D ₃	= 1N4148		
D ₄	= Led red		
Tr ₁	= BC 547		
Tr ₂ = Tr ₃	= BF 245		
Rl ₁	= Relè 12 V 3022		
T ₁ = T ₂	= Transformers 30 MHz		