

# Freedom CB/Amateur Radio Faceplates

- \* Professional Factory Looking Appearance
- \* Durable - Wear Resistant - High Gloss
- \* 3M Bond Adhesive Will Not Slip
- \* Full Color Custom Designs

- \* Precision Die-Cut Lexan Material
- \* Easy To Install - No Screws to Remove
- \* No Messy Glue - Just Peel & Stick
- \* 2 Flag Cutouts For Mic Or Radio Cover



**Galaxy DX33HML**

Model DX-33HML Fits Galaxy DX33



**Galaxy DX33HML - Connex 3300:**

Model 3300X Fits Connex 3300 & HP  
Also fits Confederate & HPCF Models

*\* This Model Has 2 Confederate Flag Cutouts*



**Cobra 25LTD Classic:**

Model 25-1 Side Microphone  
Model 25-2 Front Microphone



**Galaxy DX44HL - Connex 4400:**

Model CSA-44X Fits Connex 4400,  
4400HP, Galaxy DX44V

*\* 5 Star Model Has 2 American Flag Cutouts*

*\* LEE Model Has 2 Confederate Flag Cutouts*



**General Hill or General Lee:**

Model US General 5-Star



**General Hill or General Lee:**

Model US General Confederate

# Freedom CB/Amateur Radio Faceplates

\* This Model Has 2 American Flag Cutouts



**Cobra 29LTD Classic:**

Model 29-AF1 Side Microphone  
Model 29-AF2 Front Microphone

\* This Model Has 2 Confederate Flag Cutouts



**Cobra 29LTD Classic:**

Model 29-CF1 Side Microphone  
Model 29-CF2 Front Microphone

\* This Model Has American & Mexican Flag Cutouts



**Cobra 148GTL:**

Model 148-1 Side Microphone  
\* Available For Side Microphone Only

**COMING  
SOON!**

**New Models:** This Spot Will be Reserved For New Models As They Become Available! Keep Checking Our Website's "Sneak Preview" Section!  
<http://www.faceplates.tv>

## Features:

- \* Made from durable High Gloss Lexan Material for Permanent Lasting Durability!
- \* No messy glues or special tools required - Just remove the Knobs, peel and stick!
- \* No need to remove screws - Installs directly over the radio's existing faceplate!

## Installation:

- \* Carefully peel off the cutouts from the new faceplate and place the two flag logos on the backing for later use.
- \* Use a knife or small screwdriver to remove the knobs from the radio.  
Hint - Use one or more of the cutouts under the blade to prevent marring the radio's chrome bezel.
- \* Start the new faceplate from left to right using the bezel's indentation as a guide.
- \* Replace the knobs to finish the job - Stick the logo cutouts on top of the case or Microphone to give the unit a factory look!

Visit [www.faceplates.tv](http://www.faceplates.tv) on the Web for the latest info