

HIGH FREQUENCY PROGRAM CHART - Master Copy C

<u>Channel</u>	<u>Frequency</u>	<u>Channel</u>	<u>Frequency</u>
# 10	27.395	# 25	27.565
11	27.405	26	27.585
12	27.425	27	27.595
13	27.435	28	27.605 *
14	27.445	29	27.615
15	27.455	30	27.625
16	27.475	31	27.635
17	27.485	32	27.645
18	27.495	33	27.655
19	27.505	34	27.665
20	27.525	35	27.675
21	27.535	36	27.685
22	27.545	37	27.695
23	27.575	38	27.705
24	27.555	39	27.395
		40	27.405

Parts Needed

1. Mini toggle switch
2. Hook up wire
3. A 3k ohm resistor

* NOTE: SOME RADIOS MAY NOT KEY UP OVER 27.605. PWR LOSS MAY ALSO BE NOTED. NORMAL TRANSMITTER ALIGNMENT WILL USUALLY CORRECT PROBLEM.

