

CONVOY CON-400

Adjust L34 for maximum power.
Adjust R116 for 100% modulation.
Connect pin 5 of IC1 to 4.70V source and connect
pin 6 of IC1 to 4.70V source for adding more
frequencies.

COURIER RANGLER 40D

Adjust L119 and L120 for maximum power.
Adjust VR304 for 100% modulation.
VR103: RF panel meter adjustment.

COLT 480/1000

Adjust T6, L7, L11, and L13 for maximum power.
Adjust RV12 for 100% modulation.
RV11: SSB mike gain adjustment.
VR4: AM power adjustment.
RV3: RF power meter adjustment
RV1: Antenna warning indicator control adjustment

COURIER BLAZER 40D

Adjust T13 and L9 for maximum power adjustment.
Adjust VR9 for 100% modulation.
VR6: TX panel meter adjustment.

COBRA 32XLR

Clip CD11 next to 5014 XFMR for 100% modulation.

COBRA 140GTL

VR6: AM power adjustment.
VR7: SSB power adjustment.

COBRA 21 GTL

Adjust L10 for maximum power.
Adjust VR5 for 100% modulation.

COBRA 25GTL

Adjust L10 for maximum power.
Adjust VR5 for 100% modulation.