


TURNER MIKE EXPANDER

500 AMC DISABLE



1. Remove knobs from top of Mike.
2. Remove four screws from bottom of case and remove the P/C Board.
3. Cut the diode and fold back.
4. Reinstal in case make sure the battery clips are in place.