## CENTURION PLL

- 1. HOW TO SHIFT THE CHANNEL FREQUENCY ON THE CLARIFIER CONTROL ON TRANSMITTER MODE.
  - A. The channel frequency will be shifted each side (plus & minus) 1.5KHz by the clarifier control.
    - (1) Eliminate D39 (1S2473).
    - (2) Remove R119 (220 OHM) from the P.C.B., and connect a 100 OHM ½watt resistor between the cathode side of D36 (WZ061) and the junction of D48, C103, and C104.
  - B. In addition to the above mentioned, the channel frequency will be shifted for minus 4.5KHz by the clarifier control. In other words, frequency will be shifted plus 1.5KHz, minus 4.5KHz.

## GLADIATOR PLL

- 1. HOW TO SHIFT THE CHANNEL FREQUENCY BY THE CLARIFIER CONTROL ON TRANSMITTER MODE.
  - A. The channel frequency will be shifted each side (plus & minus) 1.5KHz by the clarifier control.
    - 1. Eliminate D30 (1S2473).
    - 2. Remove R116 (220 OHM) from the P.C.B., and connect a 100 OHM ½watt resistor between the cathode side of D36 (WZ061) and the junction of D48, C103, and C104.
  - B. In addition to the above mentioned, the channel frequency will be shifted for minus 4.5KHz by the clarifier control. In other words, frequency will be shifted plus 1.5KHz, minus 4.5KHz.
    - 1. Short circuit RT16 and RT18, and omit RT17.

## FANFARE 350/SPARTAN PLL

- 1. HOW TO SHIFT THE CHANNEL FREQUENCY BY THE CLARIFIER CONTROL ON TRANSMITTER MODE
  - A. The channel frequency will be shifted each side (plus & minus) 1.5KHz by the clarifier control.
    - 1. Eliminate D24 (1S2473).
    - 2. Remove 61 (100 OHM) from the P.C.B., and put it on between the cathode side of D26 (WZ071) and the conjuct position of D32 & R106 at bottom side of P.C.B.
  - B. In addition to the above mentioned, the channel frequency will be shifted for minus 4.5KHz by the clarifier control. In other words, frequency will be shifted plus 1.5KHz, minus 4.5KHz.
    - 1. Short circuit R132 and omit R60.

FREQUENCY of OPERATION USING 11.1125 CRYSTAL (MHz)	CHANNEL READOUT INDICATION	FREQUENCY of OPERATION USING 11.2858 CRYSTAL (MHz)
of OPERATION USING 11.1125		USING 11.2858
27.275 27.285 27.295 27.305 27.315 27,325 27.335 27.345 27.355 27.365 27.375 27.385 27.395 27.405	27 28 29 30 31 32 33 34 35 36 37 38 39 40	27.795 27.805 27.815 27.825 27.835 27.845 27.855 27.865 27.875 27.875 27.895 27.905 27.915 27.925