

COBRA 78X

Adjust L15 for maximum RF output on channel 19

VR6: Adjust for maximum modulation

VR5: RF power meter adjust

VR7: IF gain adjust

VR3: Squelch range adjust

VR4: S meter adjust

COBRA 87GTL

Adjust L13 for maximum RFO @ channel 19

VR6: Adjust for maximum modulation

VR4: RF meter adjust

COBRA 148GTL

VR4: Carrier balance SSB

VR9: Drive bias-Adjust for 25ma on channel 19 USB

VR8: Final bias-Adjust for 50ma on channel 19 USB

VR11: SSB ALC

VR10: AM power adjust

VR6: RFPO meter

Adjust L38 for maximum RFPO on channel 19 AM

\*See information in Volume 5 of Secret CB on MB8719 chip to expand channel slider.

COLT 485

RV8: SSB AGC

RV9: AM SQ range

RV10: SSB SQ range

RV6: AM S meter

RV7: SSB S meter

RV3: Power meter

\*See Volume 3 of Secret CB for expanding channels on PLL 02A chip.

Adjust T12 for maximum on USB 19

RV2: SSB power

RV4, RV5: Balance

VR4: AM power

RV12: Adjust for 100% modulation

Adjust T4, T5, T11, T6, L7, L11, L13, for maximum power channel 19 USB