

# "OOPS, WE GOOFED"

Volume 3 page 33:

## PLL CHANNELIZER PARTS LIST & EXPANDED DIAGRAM

### Parts List

- 1) G.C. Electronics 3 station push button switch(interlock type) #35-922
- 1) Radio Shack chassis #270-251
- 1) 1 watt 470 ohm resistor
- 1) ¼ watt 4.7K ohm resistor
- 1) Red LED (jumbo, 1<sup>3</sup>/<sub>4</sub> size)
- 1) Green LED " "
- 1) Yellow LED " "

