

SCANNER PROGRAMMING TIPS

If you own (or sell) Regency Scanners, here is an "out of band" programming hint you will want to know about.

K100-Push Manual, Decimal Point, then program frequency.

K500-Push Program, Decimal Point, enter frequency.

M100-Touch Decimal Point, enter frequency.

M400-Touch Decimal Point, enter frequency.

You can pick up CB transmissions and aircraft by programming as above and adding an AM detector. A simple detector can be built as shown below:

