

PACE 166 (23 CHANNEL VERSION)

MODIFICATION:

- A. Open post of channel switch to pin 4 of U2
- B. Modification A and open pin 5 of U2
- C. Switch wires on pins 3 & 4 of U2 - (pin 5 open)
- D. Disconnect wire from pin 3 of U2 (pin 4 connected/
pin 5 closed)

FREQUENCIES:

Channel	A	B	C	D
1	28	26.535		
2	29	26.545		
3	30	26.555		
4	32	26.575		
5	33	26.605		
6	34	26.615		
7	35	26.635		
8	37	26.645		
9	38	26.655		
10	39	26.665		
11	40	26.685		
12	27.425	26.695		
13	27.435	26.715	26.795	26.955
14	27.445	26.705	26.805	1
15	27.455	26.715	26.815	2
16	27.475	26.735	26.835	3A
17	27.485	26.745	26.845	4
18	27.495	26.755	26.855	5
19	27.505	26.765	26.865	6
20	27.525	26.785	26.885	7A
21	27.535	26.795	26.895	8
22	27.545	26.805	26.905	9
23	27.575	26.835	26.935	11A
24-40	NORMAL			