



Consumer Response Group

6500 W. Cortland Street * Chicago, IL 60707 * Phone: 773-889-8870 * FAX: 773-622-2269

July 18, 2001

Page 1 of 1

TECHNICAL SERVICE BULLETIN 10008

- MODEL(S):** All versions of the 29LTD
- DESCRIPTION:** Meter needle sticks after transmit, and there is no receive. Pushing the Soundtracker button (if equipped) may restore proper operation.
- ACTION:** At this time the specific cause is unknown, but appears to be influenced by the antenna configuration. Attempting to duplicate the symptom is extremely difficult. Recommendations:
- Check and adjust the SWR. Even if the SWR looks good, try adjusting it.
 - Try relocating the antenna (if possible).
 - On a mirror-mount antenna, connect a #14 (or larger) ground wire from a bolt on the antenna bracket to a bolt on the door hinge.
 - Connect a ground wire to a screw on the side of the radio.
 - As a last resort try a different antenna.
- ADJUSTMENTS:** Check and adjust the SWR.
- NOTES:** None.