



Consumer Response Group

6500 W. Cortland Street * Chicago, IL 60707 * Phone: 773-889-8870 * FAX: 773-622-2269

February 22, 2008

Page 1 of 2

TECHNICAL SERVICE BULLETIN

10056

MODEL(S): CB models 25 and 29 (all versions)

DESCRIPTION: Adding talkback

ACTION: Talkback can be easily added to these radios by installing a resistor from the sleeve of the external speaker connector to ground. See page 2 for a picture of the location.

Adding a resistor will give a fixed audio level on the talkback. Try starting with a 100 ohm resistor, and adjust as needed for the desired volume level.

If an adjustable talkback level is desired, a potentiometer can be used in place of the resistor. A 200 ohm potentiometer is recommended.

ADJUSTMENTS: None.

NOTES: None.

