

NOTE: Symbols next the screws indicate as follows.

⊕	XYN26 + C5FXS	⊕	Screw w/Washer, 2.6mmφ × 5mm
⊕	XSB3 + 4FXS	⊕	Screw, Bind 3mm4 × 4mm
⊕	XYN3 + F10FXS	⊕	Screw w/Washer, 3mmφ × 10mm
⊕	XSB3 + 8FXS	⊕	Screw, Bind 3mmφ × 8mm
⊕	XYN3 + C6FXS	⊕	Screw w/Washer, 3mmφ × 6mm
⊕	XYN3 + F8FXS	⊕	Screw w/Washer, 3mmφ × 8mm
⊕	XYN3 + F8FXS	⊕	Screw w/Washer, 3mmφ × 8mm
⊕	XYN3 + C12FXS	⊕	Screw w/Washer, 3mmφ × 12mm




Figure 22. Exploded View – Model 14T410