

Tube Filaments and Amplifier Indicator Lite Relay Keyer Voltage

All voltages measured to chassis grd. ± 10%
Relay shown in transmit pos.
All resistance in ohms.
* For frequency change these units must be adjusted.

No 2	JB 76 (BE)	USA SERIES E
BASE RF AMPLIFIER		
WAWASEE ELECTRONICS INC		
SYRACUSE INDIANA 46567		
Oct 1977	CR JM	DEW RM