

PEARCE SIMPSON CHEETAH, BENGAL, SIMBA  
15KC SLIDER

- (1) Remove the unit from its cabinet and locate the white wire on the clarifier.
- (2) Remove the wire and place an RF choke in series with the wire and capacitor as shown.
- (3) The RF choke is made from fixed value RF chokes connected in series. See note below.

NOTE: For the Simba and Cheetah the RF choke is made from a 10 UH and 1 UH connected in series. A Miller #4204 can be used and adjusted.

For the Bengal a variable Miller #4204 can be used or any adjustable coil with a 3 to 15 UH range.

